

# Installing New Materials

Go to the root folder on the installation CD or to the root installation folder if installing from a downloaded file ( ie C:\PhotoGrav3\ ). There is a folder listed there called "New Materials". Copy all the .bmp files into the following folder:

C:\Program Files (x86)\ImageLaz\PhotoGrav 3\MATERIAL\

Then copy the pg.mtl file into the following folder:

C:\Program Files (x86)\ImageLaz\PhotoGrav 3\

You will now see 13 additional wood materials listed when running PhotoGrav.